

***Qik*DRIVE**

&

***Qik*CACHE**

Windows 98 Software Installation

User Guide

P/N: UI00502

Copyright © 1999 Platypus Technology Holdings Ltd.

Every effort has been made to ensure that the information contained within this document is accurate, but no warranty is implied. Platypus Technology Holdings Ltd and its subsidiaries take no responsibilities for any loss or damages arising from the use of information contained within this guide.

All information contained in this document is subject to change without notice. All rights reserved.

All brand names and registered trademarks in this document are the property of their respective owners.

Product Use

Platypus Technology Holdings Ltd products are not intended for use in medical, life saving, or life sustaining applications.



Contents

Software Installation	4
Windows 98.....	5
Contacting Platypus Technology.....	7

BLANK

Software Installation

Thank you for purchasing a *QikDRIVE* or *QikCACHE* PCI card. From this point on the *QikCACHE* will be referred as a *QikDRIVE* as installation instructions are the same for both products. The only difference being that the *QikCACHE* does not have secondary power support for retaining information. If you have purchased a *QikCACHE*, ignore references to secondary power.

The *QikDRIVE* is shipped with a driver that supports Microsoft operating systems and a driver for the Linux operating system. The Microsoft operating systems supported are, Windows NT 4, Windows 95, Windows 98 and Windows 2000. Follow the instructions below to correctly install the driver for the operating system installed on your system.

New drivers and the latest revision of current drivers for your *QikDRIVE* can be downloaded from the Platypus Technology web page.

www.platypus.net

From this URL select *Support* and then select *Software Archive* to find the latest drivers. If you experience any difficulty, contact Platypus Technology technical support as described on page 7.

Windows 98

1. Turn on the computer and boot Windows 98.
2. After logging in, Windows 98 should report that a new **PCI SCSI Bus Controller** has been found. Click on the **<Next>** button to install a new driver and bring up the following dialog box:
3. Ensure that the recommended option is selected (as shown above) and click on the **<Next>** button.
4. Insert the supplied *QikDRIVE* Driver CD into the CD-ROM drive, and click on the **<Next>** button.
5. Windows should report that it has found the driver.
6. Click on **<Next>** to complete installation of the driver.
7. Windows has finished copying the driver from the installation disk. Click on **<Finish>**.
8. Go to the Device Manager and inspect the Disk Drives node on the device tree. There will be a PLATYPUS *QikDRIVE* for each installed card in the system.
9. Select the drive **<Properties>** button and show the **Settings** property sheet.
10. If the **Int 13 unit** checkbox is not selected, then activate it and select **<OK>**.
11. Repeat the previous step for each *QikDRIVE* installed on the system.
12. Windows 98 may prompt you to restart your machine. If so, remove the driver disk from the floppy drive and click on **<Yes>** to reboot your machine.
13. You may now partition the *QikDRIVE* using the FDISK utility in a Windows 98 DOS box. Once you have created your partitions on any installed *QikDRIVES*, FDISK requires that you reboot your machine.

14. Once Windows 98 has restarted, you may right-click on the drive in Explorer and format the drive with any file system supported by your installation of Windows 98.
15. Even without an external plug-pack connected, your *Qik*DRIVE contents will survive a warm-boot (ie. <ctrl-alt-del> or hard reset).

Contacting Platypus Technology

If you have tried the solutions recommended in this manual and are still having problems getting the *Qik*DRIVE to work properly, please contact Platypus Technology Technical Support as described below.

Contact Via Internet

www.platypus.net

UNITED KINGDOM

Platypus Technology Ltd.
Unit 3, Tealgate, Charnham Park
Hungerford Berkshire RG17 0YT, UK
Telephone +44 (0) 1488 689 211
Facsimile +44 (0) 1488 689 212

UNITED STATES

Platypus Technology Inc.
79 East Wilder Road
West Lebanon, New Hampshire 03784
Telephone +1 603 298 7455
Facsimile +1 603 298 7457
Toll Free +1 877 718 8900

AUSTRALIA

Platypus Technology Pty. Ltd.
ACN 056 130 182
Level 2, 38 Oxley Street
Crows Nest NSW 2065
Telephone +61 (0) 2 9460 6860
Facsimile +61 (0) 2 9439 7045